INSTRUCTIONS FOR DISHWASHER USE

As of 2025, all built-in and freestanding dishwashers provided by Breakfast Club of Canada have an NSF-certified sanitizing cycle.

Options du lave-vaisselle	Verrouillage des commandes Mémoire du cycle auparavant Distibuteur d'agent de rinçage réglable avec indicateur Sanitizé (NSF) Régulateur de température

*You must make the necessary arrangements to have your newly delivered dishwasher installed by a **licensed plumber**.

IMPORTANT:

- Make sure the Sanitized light on the control panel is on before starting every load.
- This cycle heats the water to a temperature that is high enough to kill germs on dishes and cookware.



If your dishwasher panel does not have a Sanitized option, you will have to use a chemical sanitizer instead.

A food-grade sanitizer uses chemical disinfectants to maintain hygiene by killing a broad spectrum of microorganisms.

- Mix the designated product with water, as indicated in the manufacturer's instructions, and spray onto dishes once the wash cycle is complete.
- Let air-dry completely before removing the dishes from the rack.

By following these instructions, you will ensure that you meet all provincial or territorial standards with regard to food safety and sanitation.